

---

**SAFETY DIRECT LTD.**

---



***Fall Protection Equipment Manufacturer***

P.O. Box 3026  
Sherwood Park, Alberta T8H 2T1

Phone: (780) 464-7139 Fax: (780) 464-7652

e-mail: [inquiries@safetydirect.ca](mailto:inquiries@safetydirect.ca)

Web site: [www.safetydirect.ca](http://www.safetydirect.ca)

**Instructions for Safety Cradles; Fire, Propane, & Water**




 **MPCC101 Propane Cylinder  
Lifting Cradle**



 **MFCC101 Fire Extinguisher  
Lifting Cradle**



 **MWCC101 Water Cooler  
Lifting Cradle**

## **Warning**

**Failure of the user to read and understand all instructions for use of this equipment may result in serious injury or death.**

## **General Instructions**

**All warning labels and instructions must be understood and followed by the user before using this product.**

**These lifting cradles must not be altered or modified in any way.**

**These cradles are individually marked and should only be used to lift designated items. Use of these cradles for equipment not identified on the labels may result in overloading or improper fitting, which can result in items falling out of cradle.**

**All closures and straps on cradles must be closed completely to properly contain item.**

**Any cradle exhibiting deterioration or deformities must be removed from service immediately.**

## **Usage Instructions**

**Each cradle should be inspected before use. See Inspections.**

**After item is securely fastened into the cradle it may be lifted to designated work area.**

**All rope or lanyards used to lift cradle should match the lifting capabilities of the cradle and should be inspected before use.**

**Wherever possible a tag line should be used to prevent or reduce the possibility of cradle swing.**

## **Inspection**

**All cradles should be inspected by user before each use and should be inspected by a competent person, other than user, on an annual basis. Record of these inspections should be kept in a log.**

**When inspection reveals any defects the cradle must be removed from service immediately.**

**The cradle should be removed from service immediately if an inspection reveals any of the following:**

- A) A cradle has been subjected to a drop greater than 3 meters.**
- B) Evidence of corrosion or deformation of the lifting D, including cracks, sharp edges chemical or excessive heat.**
- C) Alteration of the cradle by addition or removal of any parts.**
- D) The removal or illegibility of original labeling.**
- E) Damage to webbing material including, burns, tears, cuts, and contamination.**
- F) Damage to stitching patterns, pulled stitching, and frays**

## **Care and Maintenance**

**Maintenance of equipment should be carried out in accordance with instructions provided by Safety Direct Ltd. Any unusual issues should be addressed with Safety Direct Ltd.**

**All Cradles should be stored in a clean, dry area with limited exposure to the following:**

- 1) Sunlight**
- 2) Excessive heat**
- 3) Harmful fumes**
- 4) Corrosive chemicals or conditions.**

**Cradles can be cleaned with a wet sponge or rag and a mild soap solution. The use of harsh detergents or chemicals is not recommended. After cleaning the cradle should be rinsed in clean water and allowed to dry naturally. After washing, all parts of the cradle should be visibly inspected once dirt or contaminants have been removed.**

**Fall Protection You Can Live With! ®**

All rights reserved. No part of these instructions, covered by the copyrights hereon may be reproduced or copied in any form or by any means, including photocopying, recording, taping, or information storage and retrieval systems, without the written consent of Safety Direct Ltd.. Copyright ©2007 Safety Direct Ltd.. Ref: 07/07